


PrimeVOLT Installer APP (SolarHope) Quick Manual

1 APP Downloading

- Search and download “SolarHope” APP from Google Play or Apple Store.
- Scan the QR code on the inverter’s front cover to reach APP download page directly.


Note: The APP should access with some permissions, such as device’s location. Please grant all rights that APP required.



2 Connecting the Inverter

Step 1: Turn on switches of both DC and AC sides to power on inverter. LED indicator on the inverter’s front cover will be flashing.


Step 2: Open APP, follow below instructions to connect to inverter.




3 Checking Inverter Information

Defaultly, users will login in Guest mode, which can check the information about inverter.

- Click **Chart** to check the information about generation data.
- Click **Log** to check the information about historical log.



- Click **Console** to check the information about basic setting (including inverter firmware version, Standard code, and grid protection settings).



Inverter firmware version

Standard code setting and Grid protection settings

4 Regional Safety Settings

4-1 Description

Regional Safety Setting (Grid Code Setting) is a mandatory selection when configuring the system; if not selected the system will not operate. For convenience the Regional Safety Settings are set by selecting the Region from the provided list in SolarHope APP. The list is maintained with the latest setting required by AS/NZS4777.2:2020. Selection of a region will automatically match to its Power Quality Response Mode settings, including:

- Voltage balance mode (where available)
- Voltage and frequency limits
- Sustained operation for frequency variations
- Grid Protection
- Power Rate Limits
- Frequency Response Limits
- Voltage Disturbance Withstand
- Volt-Var response
- Volt-Watt response
- Fixed Power Factor Mode
- Reactive Power mode

4-2 Login as Administrator

Go to **Console > Access Management > Change User** page, and click **LOGIN AS ADMINISTRATOR**.

- Access management
- Change user level
- Input Administrator password

The first screenshot shows the 'Access Management' menu with 'Change User' and 'Change Access Level' highlighted. The second screenshot shows the 'Login as Administrator' screen with a password input field and 'LOGIN AS ADMINISTRATOR' and 'LOGIN AS GUEST' buttons.

Note:

- Click **LOGIN AS ADMINISTRATOR** to enter the administrator mode, and set Standard Code.
- Click **LOGIN AS GUEST** to enter the guest mode, and view or check Standard Code only.

i Please contact PrimeVOLT service center to get the password to enter the administrator mode.

4-3 Set Standard Code

Go to **Console > Grid Parameters** page, select region from **Standard Code** list.

- Console > Grid Parameters
- Grid Parameters Page
- Standard codes to select

The first screenshot shows the 'Grid Parameters' page with the 'Standard Code' dropdown menu open, showing options like 'AU (AS/NZS4777.2:2020 Australia A)'. The second screenshot shows a list of standard codes with a 'CANCEL' button at the bottom.

- i**
1. Please inquire local grid operator about the right **Standard Code** to select.
 2. All PrimeVOLT inverters exported to Australia and New Zealand markets meet AS/NZS4777.2:2020 requirements, with firmware support **Standard Code** setting.
 3. Please contact PrimeVOLT service center and distributors for assistant if meet confront difficulties during installation.

5 Starting Inverter

Go to **Quick Setup** page, and follow the instructions below to start inverter.

The first screenshot shows the 'Quick Setup' page with various power and production statistics. The second screenshot shows a list of parameters to be configured, such as 'Power control', 'Meter location', and 'Maximum feed in grid power(W)'. The third screenshot shows the 'Hybrid work mode' selection screen. The fourth screenshot shows the 'Start Inverter' button.

Configure export power control parameters.

Select Hybrid work mode, and set parameters.

Start Inverter.